



TM22 LR / WMR BOLT ACTION
TM22 LR / WMR STRAIGHT PULL
USER MANUAL

“ THANK YOU FOR CHOOSING A DERYA ARMS PRODUCT ”

THIS BOOKLET WILL GUIDE YOU THROUGH HANDLING YOUR RIFLE SAFELY



**PLEASE NOTE: CHANGES MAY BE
MADE WITHOUT NOTICE**

Your rifle features an innovative and unique design. With regular care and cleaning, your rifle will serve you for a life time. The rifle was manufactured by DERYA ARMS from high quality raw materials and with high-tech CNC machines in our factory.

Please read and understand all the directions and instructions in this Manual to guarantee the best performance and a safe shooting experience. Maintain your rifle properly in accordance with these instructions so it will remain safe, and performs properly.

Always remember that you are using a rifle; always follow all safety rules and be aware that it is your responsibility to share your knowledge, and educate others in the safe use of this rifle.

Before firing a cartridge, learn the parts of your rifle and understand how it operates. Please read this manual carefully and enjoy your rifle safely.

MAINTENANCE INSTRUCTIONS:

1) NEVER MAKE CHANGES OR ALTERATIONS TO YOUR RIFLE

This rifle was built to a proven and tested design, and manufactured with care. It must NEVER be altered or changed. Changing or altering any part of your rifle may result in serious injuries to you or others, and is NOT RECOMMENDED by the manufacturer. Any changes made to the rifle or use of non-factory parts voids the factory warranty.

2) PROPER CARE AND STORAGE

Regular care and cleaning of your rifle is key to its proper functionality and reliability. ALWAYS make sure that the rifle is UNLOADED before you leave the range and check it again before you start the cleaning process.

THE RESPONSIBILITIES OF THE USER

The laws of your country give you the right to possess a hunting rifle. Appreciate and enjoy your rights with care. Be aware that, as an owner of a rifle, you are responsible for ensuring your own safety and that of your shooting partners, observers, and the environment.

DISCLAIMER

This rifle is sold with the understanding that the buyer will obey all applicable domestic laws, therefore Derya Arms is not responsible for death or injuries caused by incorrect or irresponsible use.



DERYA ARMS DOES NOT ACCEPT ANY RESPONSIBILITIES FOR DAMAGE DUE TO THE FOLLOWING CAUSES

- 1) INCORRECT OR IRRESPONSIBLE USE OF THE RIFLE**
- 2) USE OF INCORRECT CALIBER AMMUNITION OR RELOADED, DAMAGED OR IMPROPER CARTRIDGES**
- 3) INSUFFICIENT AND/OR INCORRECT MAINTENANCE OR CLEANING WHICH CAUSES TO DAMAGE OR WEAR**
- 4) SALE CONTRARY TO APPLICABLE LAWS AND REGULATIONS**
- 5) CHANGING OR CONVERSION OF THE RIFLE'S ORIGINAL DESIGN, OPERATING MECHANISM, ACCESSORIES, MAGAZINES OR MECHANICALS**
- 6) CARELESS, DANGEROUS OR CRIMINAL USE**
- 7) USING THE RIFLE WITHOUT FIRST READING, UNDERSTANDING AND FOLLOWING ALL SAFETY RULES**
- 8) ANY OTHER USE OR ACTION THAT IS BEYOND THE DIRECT CONTROL OF THE MANUFACTURER**

IMPORTANT WARNING

- 1) Read the instructions booklet completely before using your rifle.**
- 2) Always be aware of the handling and functional characteristics of your rifles.**
- 3) Always unload your rifle when not in use (remove all cartridges).**

When stored or not in use, rifles should always be unloaded and move the safety lever to the SAFE position to block the trigger of your rifle.

Always remove all cartridges and inspect the chamber to ensure your rifle is unloaded.

- 1) After shooting.**
- 2) Before racking or after picking up the rifle.**
- 3) Before putting the gun into its case.**
- 4) Any time you are not using your rifle.**
- 5) Before handing your gun to anyone else.**
- 4) ALWAYS KEEP YOUR RIFLE POINTED IN A SAFE DIRECTION.** This ensures you do not injure yourself or anyone else.
- 5) ALWAYS STORE YOUR RIFLE OUT OF REACH OF CHILDREN OR OTHER UNAUTHORIZED PEOPLE.** There are many ways of keeping your rifles locked and stored safely and securely. Always secure your rifle in accordance with applicable laws in your area and always unload and then lock the rifle when not in use or whenever it will be unattended.

6) ALWAYS OBEY ALL LAWS REGARDING OWNERSHIP, TRANSPORT, AND SHOOTING YOUR RIFLE. Never point your rifle at a person. Do not harm any person or damage any public property.

7) IF YOUR RIFLE DOES NOT FIRE AFTER PULLING THE TRIGGER: STOP, WAIT A MINUTE, AND USE EXTRA CAUTION WHEN OPENING THE BOLT. If your rifle did not fire after pulling the trigger STOP! Keep the rifle pointed in a safe direction, apply the safety by moving the safety lever to the safe position. Wait 60 seconds. Carefully open the action by pulling the bolt or operating handle and eject the cartridge in a safe direction. Always remember when you experience a misfire, your rifle is still loaded and could fire at any time (a "hang fire").

8) ALWAYS TREAT YOUR RIFLE AS IF IT IS LOADED, EVEN WHEN THE SAFETY IS ON. Always keep your finger away from the trigger unless you are on target and prepared to shoot. Never forget that even with safety ON, you are responsible for the direction your rifle is pointing. Do not count on a mechanical device.

9) This rifle was produced under the control and supervision of Derya Arms. The rifle must never be altered. Derya does not recommend the use of any spare parts or accessories and magazines other than those included in the original box or received from Derya. If you need magazines, spare parts or repair, contact our authorized distributor in your country or Derya Arms ONLY.

10) ENSURE THE BARREL IS NOT PLUGGED OR OBSTRUCTED BEFORE YOU LOAD YOUR GUN. The barrel should not have any residue from bore cleaning solvent or oil, or any other foreign material inside the bore, chamber or choke. If the barrel is blocked or otherwise obstructed, even partially, this may cause bulging and/or a breech explosion and/or a split barrel. If you feel a strange recoil or the report sounds unusually loud or soft STOP SHOOTING IMMEDIATELY and check the barrel for obstructions and bulges.

NEVER try to clear an obstruction in your barrel by firing another ammunition!

ANY PARTIAL OR COMPLETE BORE OBSTRUCTION can cause serious injury or death to the shooter or bystanders.

SERIAL NUMBER

The serial number is engraved on the rifle on several places. Every rifle has a unique number. This number is used for legal and warranty matters. Derya suggests that owners note and store the serial numbers of all of your rifles in a secure location away from the rifles.

KEEP THIS CARD FOR YOUR RECORDS

Serial Number _____

Date Of Purchase _____

Place Of Purchase _____



STATE-BY-STATE WARNINGS



CALIFORNIA STATE WARNING

CHILDREN ARE ATTRACTED TO AND CAN OPERATE FIREARMS THAT CAN CAUSE SEVERE INJURIES OR DEATH. PREVENT CHILD ACCESS BY ALWAYS KEEPING FIREARMS LOCKED AWAY AND UNLOADED WHEN NOT IN USE. IF YOU KEEP A LOADED FIREARM WHERE A CHILD OBTAINS AND IMPROPERLY USES IT, YOU MAY BE FINED OR SENT TO PRISON. IT IS UNLAWFUL TO USE A MAGAZINE WITH A CAPACITY OVER 10 ROUNDS.



MASSACHUSETTS STATE WARNING

IT IS UNLAWFUL TO CARRY ANY MAGAZINE OR BELT WHICH HOLDS MORE THAN TEN ROUNDS, UNLESS AUTHORITY IS GRANTED BY THE BOSTON POLICE COMMISSIONER. IT IS UNLAWFUL TO STORE OR KEEP A FIREARM, RIFLE, SHOTGUN OR MACHINE GUN IN ANY PLACE UNLESS THAT WEAPON IS EQUIPPED WITH A TAMPER RESISTANT SAFETY DEVICE OR IS STORED OR KEPT IN A SECURELY LOCKED CONTAINER.



NEW YORK STATE WARNING

IT IS UNLAWFUL TO CARRY ANY MAGAZINE OR BELT WHICH HOLDS MORE THAN SEVEN ROUNDS, UNLESS AUTHORITY IS GRANTED BY THE STATE OF NEW YORK. THE USE OF A LOCKING DEVICE OR SAFETY LOCK IS ONLY ONE ASPECT OF RESPONSIBLE FIREARMS STORAGE FOR INCREASED SAFETY; FIREARMS SHOULD BE STORED UNLOADED AND LOCKED IN A LOCATION THAT IS BOTH SEPARATED FROM THEIR AMMUNITION AND INACCESSIBLE TO CHILDREN AND OTHER UNAUTHORIZED PERSONS.

SAFETY PRECAUTIONS

CHILDREN ARE ATTRACTED TO FIREARMS, AND MIGHT BE ABLE TO OPERATE THEM, THEY CAN CAUSE SEVERE INJURIES AND EVEN DEATH, TO THEMSELVES OR OTHERS. PREVENT CHILDREN FROM ACCESS, ALWAYS KEEP YOUR FIREARMS LOCKED AWAY, UNLOADED AND OUT OF REACH OF CHILDREN WHEN NOT IN USE AT ANY TIME.

THE FIREARM SHOULD BE STORED IN ROOMS WITH A DRY ATMOSPHERE AND MINIMUM HUMIDITY. IT SHOULD NOT BE STORED ENCASED IN LEATHER OR ANYTHING THAT WILL ATTRACT AND HOLD MOISTURE, CAUSING IT TO RUST.

DO ALL PROCEDURES (DISASSEMBLY, CLEANING AND OTHER MAINTENANCE) ONLY WHEN THE FIREARM IS UNLOADED. BE SURE THAT THE MAGAZINE, AND CHAMBER ARE EMPTY WHILE YOU ARE PROCEEDING. CHECK EJECTION PORT, AND CHAMBER VISUALLY.

WHEN STORING THE GUN FOR A PROLONGED PERIOD OF TIME, IT IS NECESSARY TO OIL IT HEAVILY WITH AN ACID-FREE LUBRICANT. THE EXTERNAL PARTS MUST BE COATED WITH AN ANTI-RUST OIL OR GREASE TO PREVENT MOISTURE CAUSING THE PARTS TO RUST AND MALFUNCTION. BEFORE USAGE, THE SHOTGUN MUST BE CLEANED AND WIPED DRY AGAIN.

TECHNICAL SPECIFICATIONS OF THE BOLT ACTION RIFLE

Model	TM22 BA-18
Caliber	.22LR
Action	Bolt Action
Capacity*	10+1 Rounds
Barrel Length	457.2mm / 18" & 500mm / 20"
Overall Length	930mm / 36.6" & 973mm / 38.3"
Overall Width	40mm / 1.6"
Length of Pull	350mm / 13.7"
Weight, Empty	2,00 kg / 4.4 lb. & 2,10 kg / 4.62 lb
Weight, Loaded	2,10 kg / 4.62 lb. & 2.2 kg / 4.85lb.
Stock	Synthetic

Model	TM22M BA-18
Caliber	.22WMR
Action	Bolt Action
Capacity*	10+1 Rounds
Barrel Length	457.2mm / 18" & 500mm / 20"
Overall Length	930mm / 36.6" & 973mm / 38.3"
Overall Width	40mm / 1.6"
Length of Pull	350mm / 13.7"
Weight, Empty	2,00 kg / 4.4 lb. & 2,10 kg / 4.62 lb
Weight, Loaded	2,10 kg / 4.62 lb. & 2.2 kg / 4.85lb.
Stock	Synthetic

*AVAILABLE AFTERMARKET 15RD / 25RD MAGAZINES

DISASSEMBLY OF THE BOLT ACTION RIFLE

1) Press the button located on the top of the receiver to release the bolt.

2) While keeping the button pressed, pull the bolt in the direction indicated by the arrow to remove it from the receiver.



3) Ensure the magazine is detached from the rifle.

4) Using a 5mm Allen key, remove the screw located under the handguard.

5) Gently separate the stock from the receiver.




6) Using a 3mm Allen key, remove the front screw located under the receiver.

7) Using a 3mm Allen key, remove the rear screw located under the receiver.

8) Pull the barrel in arrow direction.



9) To reinstall the bolt, align the two locking lugs with the guide rails inside the receiver and insert the bolt into the bolt channel.



CAUTION!

Remove the bolt completely before disassembling the rifle

SAFETY GUIDE



The "safety" is in the on safe position.



The "safety" is in the off safe position.

TYPES OF MAGAZINES



.22LR Magazine




.22WMR Magazine

AFTER MARKET



10, 15, and 25-round magazines are available. Please contact your distributor for more information.



VERSATILE ATTACHMENT OPTIONS

A Picatinny rail is located under the removable fore-end cap, and the 1/2x28 universal thread dimensions allow you to attach any compatible muzzle device accordingly.

TM22 BOLT-ACTION PARTS LIST



P.NO	PART NAME
1	Receiver
2	Bolt Retaining Screw
3	Locking Detent Ball
4	Locking Spring
5	Locking Screw
6	Follower
7	Follower & Trigger Lever Spring
8	Follower Pin
9	Tube Cap
10	Hammer Spring
11	Hammer
12	Firing Pin
13	Tube O-ring
14	Tube
15	Bolt Handle
16	Bolt Knob
17	Bolt Knob Screw
18	Left Extractor
19	Bolt
20	Right Extractor Spring
21	Right Extractor
22	Firing Pin Spring
23	Left Extractor Spring
24	Extractor Pin
25	Magazine Release Lever Pin
26	Magazine Release Lever
27	Magazine Adapter
28	Trigger Group Assembly Screw
29	Magazine Adapter Pin
30	Trigger & Trigger Lever Pin
31	Magazine Release Lever Spring
32	Trigger
33	Disconnecter

P.NO	PART NAME
34	Trigger Lever
35	Trigger Spring
36	Trigger Assembly
37	Ejector
38	Ejector Pin
39	Ejector Spring
40	Cheekpiece
41	Cheekpiece Retainer Nut
42	Cheekpiece Connector
43	Cheekpiece Screw
44	Cheekpiece Nut
45	Recoil Pad
46	Stock Screw
47	Synthetic Stock
48	Rear Sling Swivel
49	Safety Spring
50	Safety Screw M4x4
51	Safety Pin
52	Safety
53	Grip Cap
54	Rear Sight Top-Bottom Adjustment Screw
55	Rear Sight Slide
56	Rear Sight Spring
57	Rear Sight Aperture
58	Rear Sight Right-Left Adjustment Screw
59	Rear Sight
60	Front Sight Screw
61	Rear Sight Pin
62	Magazine 10rd
63	Front Sling Swivel
64	Picatinny Cover
65	Barrel Pin
66	Barrel Centering Pin

P.NO	PART NAME
67	Front Sight
68	Front Sight Cover
69	Universal Barrel Nut
70	Barrel
71	Disconnecter Connection Pin
72	Trigger Connection Pin


Note:

Some models will vary from exploded view.

There may be some changes on the user manual. Please use that code to download the latest version of manual.



TM22 BOLT ACTION



TM22M BOLT-ACTION PARTS LIST



P.NO	PART NAME
1	Receiver
2	Bolt Retaining Screw
3	Locking Detent Ball
4	Locking Spring
5	Locking Screw
6	Follower
7	Follower & Trigger Lever Spring
8	Follower Pin
9	Tube Cap
10	Hammer Spring
11	Hammer
12	Firing Pin
13	Tube O-ring
14	Tube
15	Bolt Handle
16	Bolt Knob
17	Bolt Knob Screw
18	Left Extractor
19	Bolt
20	Right Extractor Spring
21	Right Extractor
22	Firing Pin Spring
23	Left Extractor Spring
24	Extractor Pin
25	Magazine Release Lever Pin
26	Magazine Release Lever
27	Trigger Group Assembly Screw
28	Trigger & Trigger Lever Pin
29	Magazine Release Lever Spring
30	Trigger
31	Disconnecter
32	Trigger Lever
33	Trigger Spring

P.NO	PART NAME
34	Trigger Assembly
35	Ejector
36	Ejector Pin
37	Ejector Spring
38	Cheekpiece
39	Cheekpiece Retainer Nut
40	Cheekpiece Connector
41	Cheekpiece Screw
42	Cheekpiece Nut
43	Recoil Pad
44	Stock Screw
45	Synthetic Stock
46	Rear Sling Swivel
47	Safety Spring
48	Safety Screw M4x4
49	Safety Pin
50	Safety
51	Grip Cap
52	Rear Sight Top-Bottom Adjustment Screw
53	Rear Sight Slide
54	Rear Sight Spring
55	Rear Sight Aperture
56	Rear Sight Right-Left Adjustment Screw
57	Rear Sight
58	Front Sight Screw
59	Rear Sight Pin
60	Magazine 10rd
61	Front Sling Swivel
62	Picatinny Cover
63	Barrel Pin
64	Barrel Centering Pin
65	Front Sight
66	Front Sight Cover

P.NO	PART NAME
67	Universal Barrel Nut
68	Barrel
69	Disconnecter Connection Pin
70	Trigger Connection Pin


Note:

Some models will vary from exploded view.

There may be some changes on the user manual. Please use that code to download the latest version of manual.



TM22M BOLT ACTION



TECHNICAL SPECIFICATIONS OF THE STRAIGHT PULL RIFLE

Model	TM22 SP-18
Caliber	.22LR
Action	Straight Pull
Capacity*	10+1 Rounds
Barrel Length	457.2mm / 18" & 500mm / 20"
Overall Length	930mm / 36.6" & 973mm / 38.3"
Overall Width	40mm / 1.6"
Length of Pull	350mm / 13.7"
Weight, Empty	1,90 kg / 4.2 lb. & 2,00 kg / 4.4 lb.
Weight, Loaded	2,00 kg / 4.4 lb. & 2,10 kg / 4.62 lb.
Stock	Synthetic

Model	TM22M SP-18
Caliber	.22WMR
Action	Straight Pull
Capacity*	10+1 Rounds
Barrel Length	457.2mm / 18" & 500mm / 20"
Overall Length	930mm / 36.6" & 973mm / 38.3"
Overall Width	40mm / 1.6"
Length of Pull	350mm / 13.7"
Weight, Empty	1,90 kg / 4.2 lb. & 2,00 kg / 4.4 lb.
Weight, Loaded	2,00 kg / 4.4 lb. & 2,10 kg / 4.62 lb.
Stock	Synthetic

*AVAILABLE AFTERMARKET 15RD / 25RD MAGAZINES

DISASSEMBLY OF THE STRAIGHT PULL RIFLE

1) Ensure the magazine is detached from the rifle.

2) Using a 5mm Allen key, remove the screw located under the handguard.




3) Gently separate the stock from the receiver.

4) Using a 3mm Allen key, remove the front screw located under the receiver.



5) Using a 3mm Allen key, remove the rear screw located under the receiver.

6) Pull the barrel in arrow direction.



TM22 STRAIGHT PULL PARTS LIST



P.NO	PART NAME
1	Receiver
2	Barrel Centering Pin
3	Receiver Assembly Screw
4	Receiver Assembly Nut
5	Rubber
6	Rear Sight Spring
7	Rear Sight Body
8	Rear Sight
9	Rear Sight Adjustment Screw
10	Rear Sight Pin
11	Rear Sight Retaining Pin
12	Firing Pin
13	Firing Pin Spring
14	3X12 Pin
15	Out-of-Battery Safety Spring
16	Out-of-Battery Safety Screw
17	Out-of-Battery Safety Pin
18	Extractor Pin
19	Left Extractor Spring
20	Left Extractor
21	Bolt
22	Right Extractor
23	Right Extractor Spring
24	Operating Handle Spring
25	Operating Handle Link Pin
26	3x16 pin
27	Trigger Group Assembly Screw
28	Magazine Adapter
29	Magazine Release Lever
30	Magazine Release Lever Pin
31	Magazine Adapter Pin
32	Trigger & Hammer Pin
33	Magazine Release Lever Spring

P.NO	PART NAME
34	Trigger Insert
35	Trigger
36	Disconnecter Spring
37	Disconnecter
38	Trigger Spring
39	Trigger Group Assembly Nut
40	Trigger Assembly
41	Hammer Pin Sleeve Female
42	Hammer
43	Hammer Pin Sleeve Male
44	Hammer Spring
45	Ejector
46	Ejector Pin
47	Ejector Spring
48	Cheekpiece Nut
49	Cheekpiece Screw
50	Cheekpiece Adapter
51	Cheekpiece Retaining Nut
52	Cheekpiece
53	Recoil Pad
54	Stock Screw
55	Synthetic Stock
56	Rear Sling Swivel
57	Safety Spring
58	Safety Screw
59	Safety Pin
60	Safety
61	Grip Cap
62	Operating Handle Rivet
63	Operating Handle Link Retaining Pin
64	Operating Handle Link
65	Operating Handle Bar Locking Pin
66	Operating Handle Bar Locking Spring

P.NO	PART NAME
67	Operating Handle
68	Operating Handle Short Pin
69	Operating Handle Bar
70	Operating Handle Pin
71	Magazine 10rd
72	Front Sling Swivel
73	Picatinny Cover
74	Barrel Pin
75	Barrel
76	Front Sight Body
77	Front Sight Spring
78	Front sight
79	Front Sight Insert Pin
80	Trigger Connection Pin


Note:

Some models will vary from exploded view.

There may be some changes on the user manual. Please use that code to download the latest version of manual.



TM22 STRAIGHT PULL



TM22M STRAIGHT PULL PARTS LIST



P.NO	PART NAME
1	Receiver
2	Barrel Centering Pin
3	Receiver Assembly Screw
4	Receiver Assembly Nut
5	Rubber
6	Rear Sight Spring
7	Rear Sight Body
8	Rear Sight
9	Rear Sight Adjustment Screw
10	Rear Sight Pin
11	Rear Sight Retaining Pin
12	Firing Pin
13	Firing Pin Spring
14	3X12 Pin
15	Out-of-Battery Safety Spring
16	Out-of-Battery Safety Screw
17	Out-of-Battery Safety Pin
18	Extractor Pin
19	Left Extractor Spring
20	Left Extractor
21	Bolt
22	Right Extractor
23	Right Extractor Spring
24	Operating Handle Spring
25	Operating Handle Link Pin
26	3x16 pin
27	Trigger Group Assembly Screw
28	Front Sight
29	Magazine Release Lever
30	Magazine Release Lever Pin
31	Front Sight Insert Pin
32	Trigger & Hammer Pin
33	Magazine Release Lever Spring

P.NO	PART NAME
34	Trigger Insert
35	Trigger
36	Disconnecter Spring
37	Disconnecter
38	Trigger Spring
39	Trigger Group Assembly Nut
40	Trigger Assembly
41	Hammer Pin Sleeve Female
42	Hammer
43	Hammer Pin Sleeve Male
44	Hammer Spring
45	Ejector
46	Ejector Pin
47	Ejector Spring
48	Cheekpiece Nut
49	Cheekpiece Screw
50	Cheekpiece Adapter
51	Cheekpiece Retaining Nut
52	Cheekpiece
53	Recoil Pad
54	Stock Screw
55	Synthetic Stock
56	Rear Sling Swivel
57	Safety Spring
58	Safety Screw
59	Safety Pin
60	Safety
61	Grip Cap
62	Operating Handle Rivet
63	Operating Handle Link Retaining Pin
64	Operating Handle Link
65	Operating Handle Bar Locking Pin
66	Operating Handle Bar Locking Spring

P.NO	PART NAME
67	Operating Handle
68	Operating Handle Short Pin
69	Operating Handle Bar
70	Operating Handle Pin
71	Magazine 10rd
72	Front Sling Swivel
73	Picatinny Cover
74	Barrel Pin
75	Barrel
76	Front Sight Body
77	Front Sight Spring
78	Trigger Connection Pin


Note:

Some models will vary from exploded view.

There may be some changes on the user manual. Please use that code to download the latest version of manual.



TM22M STRAIGHT PULL



Warranty Certificate

Derya warranty covers its rifles and parts. We offer 2 years Warranty on our products for their intended purpose. As with any product, abuse, gunsmithing by an unqualified person and normal wear and tear are excluded. Additionally, if the rifle was modified and/or repaired by an unqualified gunsmith without permission from DERYA®, the warranty will be void.

DERYA® warrants that the enclosed rifle was originally manufactured free of defects in material, workmanship and mechanical function. DERYA® agrees to correct any defect in the rifle for the original purchaser/importer by repair, adjustment or replacement, at DERYA's® option, with the same or comparable quality components (or by replacing the rifles at DERYA's® option); provided, however, that the rifle is returned unloaded and the freight prepaid.

This warranty is null and void if the rifle has been misused, damaged (by accident or otherwise), fired with hand loaded, reloaded or improper ammunition, fired with an obstruction in the barrel, damaged through failure to provide reasonable and necessary maintenance as described in the manual accompanying the rifle, or if unauthorized repair or any alteration, including of a cosmetic nature, has been performed on the rifle.

Subject to the foregoing, this warranty confers the right to have the covered rifle or its parts repaired, adjusted or replaced exclusively upon the original purchaser, which right is not transferable to any other person. No implied warranties of any kind are made herein and this warranty does not apply to any accessory items attached or appurtenant to the rifle.

In no event shall DERYA® be liable for any incidental or consequential damages arising from or in connection with this warranty, In the event warranty service is needed, contact the dealer you purchased the rifle from; or the importer/distributor of your country; or DERYA® customer service by mailing to support@deryaarms.com.



**“HAVE YOU SEEN ANY
OTHER TM22 MODELS?”**



DERYA STORE



SOCIAL MEDIA



Derya Silah San.Ltd.
O.S.B. 41959 Sk.
No:24 42700
Konya/Turkey



+90 332 514 8118



support@deryaarms.com



www.deryaarms.com